

LVT

Maintenance Guide

There are two basic maintenance options on LVT Flooring.

Domestic

Maintenance

The floor should be swept or vacuumed on a regular basis. Dirt spots and liquids should be cleaned up as soon as possible with water. For a complete clean use a PU cleaner with damp mop with a neutral detergent followed by rinsing with clean water.

Commercial

Maintenance

The above can also be used but for larger areas a spray and buffing can be used. After an initial clean apply two light coats of a high quality commercial floor finish. The floor can then be spray buffed using a polishing machine at low settings.

Preventative

Measures

Encourage the use of protective door mats to prevent the entry of grit and sand.
Install floor protectors to the bottom of furniture to prevent scratching or marking



Perfect Flooring. In one easy step.

UK Flooring Direct Maintenance Guide

All maintenance products can be purchased from us and are can be found in our Flooring Accessories.

If you require any further advice on LVT maintenance then please call our technical department on 0844 327 5555, e-mail us on technical@ukflooringdirect.co.uk or click the Live Help Button at the top of the page.

Contact our Technical Department on 0844 327 555 or email us at technical@ukflooringdirect.co.uk

www.ukflooringdirect.co.uk